

Startup Checklist

Before switching on your lab equipment, follow our recommended pre-startup procedures checklist.



Before switching your lens surfacing systems on, we advise the following:

- Check power supply, voltage and earthing.
- Check air supply and dry air filters thoroughly to ensure there is no moisture.
- Apply grease to all slides after cleaning and move slides by hand a few times before powering up.
- Remove all old polish and refill new polish. Recycle a while after cleaning old polish containment in the polish chamber.
- For the Velocity Coater, remove old varnish and replace with new coating filter and new varnish.

Have questions or need advice regarding these guidelines?

Call: 1-800-COBURN-1 (1-800-262-8761)

Email: CustomerCareCenter@coburntechnologies.com