

NEW

VELOCITY COATER

UV HARD COATING SYSTEM

"MANUAL OR AUTOMATED OPERATION"

- Highest throughput of any coater on the market with excellent yields
- 120 lenses per hour
- LMS Connectivity
- 5 station UV coating machine incorporating:
 - Load Station
 - Wash Station
 - Coat Station
 - Cure Station
 - Unload Station
- Thermal controlled coating station keeps coating viscosity consistent
- Recipe Driven environment for coating process control
- Constant prime cycle to ensure even coating flow
- Easy access for service/diagnostics
- Automated lens loading & unloading*
- Prewash in autoloader*
- On-the-block & off-the-block processing*
- Available in manual loading configuration with autoloader
- Autoloader can be retrofitted

**Not available in manual configuration*

